ADVACAM
Imaging the Unseen


Files and directories of the Pixet and SDK

Online version:
https://wiki.advacam.cz/wiki/Files_and_directories_of_the_Pixet_and_SDK

Contents

Main directory of the Pixet program 3
User data directory 3
Subdirectories of the Pixet program 4
The factory and the configs subdirectories 4
factory 4
configs 4
logs 5
hwlibs 6
plugins 6
drivers 6
libs 6
scripts 6
Other subdirs 7
Main directory of the API-using programs, independent on the Pixet 7
Special files 9
Configuration XML files 9
pixet.ini file 9
[Settings] 9
[Hwlibs] 11
[Plugins] 11
[PixelmanPlugins] 12
Device configuration ini files 12
Device firmware files 12
Insidious complications with files/dirs 12
Related 13

Main directory of the Pixet program



Pixet main directory if all here

Here are main program files, binary libraries, API files, licence file and the pixet.ini file. Here may also be hwlibs subdirectory, special files for some devices. Their location depends on the [Hwlibs] section of the pixet.ini file.
There can also be subdirectories factory, configs and logs. They are there if UseAppDataDir is disabled in pixet.ini, in the [Settings] section.
If here are not located configs, inis and logs, this directory can be located in Program files, or in another location where the user cannot normally write.

Warning

It may be confusing that this directory contains device ini files, such as zest.ini, dummy.ini, ..., since installation, but if UseAppDataDir is enabled or AppDataDir= is set, in pixet.ini, the files located here have no effect on the devices.

User data directory

This is location of configuration and log files. The program must be able to write here.
This is used, if in the pixet.ini, in the [Settings] section is located UseAppDataDir=true (default state).

AppData - user data directory

Default location is in the user's system application data directory, like us:

- Windows C:\Users\username\AppData\Local\PixetPro
- Linux ~/.config/PixetPro
- MacOS ~/Library/Application Support/PixetPro

Notes

- Location of the directory can be changed anywhere, using the AppDataDir= line in the pixet.ini.
- Turning on UseAppDataDir does not affect the factory directory. If it is not changed using factoryDir=, it is still expected beside the running program, or in the current directory, if different.

See: #pixet.ini file

Subdirectories of the Pixet program

The factory and the configs subdirectories

The factory directory should contain the factory default configuration XML files. The Pixet core use it while starting, if the configuration file is not in the configs directory. The configs directory contain configuration XML files. The Pixet core try to use it while starting and save the current settings to it, if exiting.
(This process works the same way when you start and quit the Pixet program or if you use C API functions pxcInit/pxcExit or Python API functions pypixet.start() / pixet.exitPixet()+pypixet.exit().)
The detector cannot work properly if proper config not loaded.
See #Configuration XML files

Location of this subdirs can be in the main program directory or in user data directory, depending on the UseAppDataDir= line in the pixet.ini file.

factory

It should contain the factory default configuration XML files. The Pixet core use it while starting, if the configuration file is not in the configs directory or if user click the "Load factory config" or scripts can use it by the loadFactoryConfig() method. Location of this subdir can be in the main program directory or can be located anywhere using the FactoryDir= line in the pixet.ini file.
Hint: If you frequently do experiments with more instances of Pixet, API-using programs or scripts and have more devices, you can use single location of the factory directory for all.

Notes:

- Location of this directory not affected by the UseAppDataDir= in pixet.ini.
- File names must be exact, for example MiniPIX-D06-W0065.xml, AdvaPIX-C06-W0127-4.xml. It is the complete device name, where all spaces are replaced by minuses. If not exact, a load-factory like functions cannot find it.

See:

- #pixet.ini file - [Settings] section

configs

Contain configuration XML files for devices. The Pixet core try to use it while starting the Pixet program or in pypixet.start() method in scripts, or if the C API function pxcInit() used. And automatically save the current settings to it, while exitting the Pixet program, or if the pypixet.exit() method is used in scripts, or if the pxcExit() function used via C API.

In addition, this directory contains:

- Configuration XML files for filters - name format filtername_DevName ChipID.xml - for example "adaptiveff_MiniPIXD06-W0065.xml"
- Configuration INI files for plugins - dev specific - name format pluginname_ChipID.ini - for example "devcontrol_D06-W0065.ini"
- Configuration INI files for plugins - name format pluginname.ini - for example "pyscripting.ini"

Location of this subdir can be in the main program directory or in user data directory, depending on the UseAppDataDir= line in the pixet.ini file, or can be located anywhere using the ConfigsDir= line in the pixet.ini file.

Note: The default UseAppDataDir= in pixet.ini is enabled in Pixet installation, but disabled in API package.

See:

- #pixet.ini file - [Settings] section

logs

The logs directory

Here are log files from all hardware libraries, pixet core. Files are from last Pixet core run. While next run, the core archive last log files. Subdirectories logs1, logs2, ... contains backups for last 10 sessions.
Location of this subdir can be in the main program directory or in user data directory, depending on the UseAppDataDir= line in the pixet.ini file, or can be located anywhere using the LogsDir= line in the pixet.ini file.

- Main log file is the log.log. This is the main log of the Pixet core.

  You can see here the attempts to load hwlibs, whether any device was found, whether hwlib was able to start, load the configuration, ...

- Hwlib logs are named by each hwlib, eq. minipix.log.

  You can see here the hwlib messages. It contains detected device names, serial numbers and types.

- Device logs are named by hwlib and each device, eq. minipixtpx3_0144 A.log.

  Here are the low-level informations. It can be helpful for our Technical support if the device is naughty.

- The runtime.log.

  Simple list of init/exit times of the Pixet core.

Note: The default UseAppDataDir= in pixet.ini is enabled in Pixet installation, but disabled in API package.

See:

- #pixet.ini file - [Settings] section

hwlibs

This is the usual place for hwlib libraries, designed to work with different types of devices. The actual location of the files is defined in the [hwlibs] section of the pixet.ini file. Default is the hwlibs subdirectory of the main program running directory. But here are a simple relative paths from the main program location and can be configured without subdirectory. It is commonly used in single-purpose programs using API.
Note: The default UseAppDataDir= in pixet.ini is enabled in Pixet installation, but disabled in API package.

See:

- #pixet.ini file - [Hwlibs] section

plugins

Default location of plugins to the Pixet program.
Warning: Some plugins can be need for API too.

See:

- #pixet.ini file - [Plugins] section

drivers

Installators of drivers for some devices.

libs

Libraries for Python scripting plugin.


scripts

- Sample scripts for using Python scripting plugin.
- The default place to search for imports used in scripts run from the Python scripting plugin.

Other subdirs

- samples - Sample data for demo when using virtual file device.
- help - PDF manuals
- platforms, styles - System directories of QT.

Main directory of the API-using programs, independent on the Pixet




Directory of minimalistic program using binary API and working on computer with Visual Studio installed
(This is afther 2025.09 / for old see: old version)

User can write programs using our API. To operate them, need:


- Pixet core library - The core of the Pixet program. pxcore.dll, or pxcore.so file.
- Pixel processing library - pxproc.dll or pxproc.so library - only for Clustering and Spectral imaging use
- Static linking libraries - To compile binary programs on Windows, user need the pxcore.lib (and pxproc.lib). Only in compile time. Compiler must be setup for using it.
- Auxilliary libraries of system - If program must working on computer without an IDE installed, can need some auxilliary libs, like as: msvcp140.dll, vcruntime140.dll, etc
- pixet.ini - configuration for the Pixet core. See #pixet.ini file
- HWlibs for the given hardware (and firmwares if devices need). See #hwlibs and #Device firmware files
- Device configuration files in the factory and configs directories, or elsewhere according to the settings in pixet.ini. See #The factory and the configs subdirectories
- Place for logs in the logs directory, or elsewhere according to the settings in pixet.ini. See #logs
- Python interface - To run Python scripts, pypixet.pyd is needed in addition. And a pypxproc.pyd for Clustering and Spectral imaging objects.

Basic files are in the API packages:

The Pixet API packages



Files in the Pixet API package for Windows



Files in Pixet API package for Linux

Download at advacam.com/downloads/
Note: Pay attention to download the correct environment version (OS, 32/64 bit, x86/ARM)

pxcore.dll (or lib...so) pxcore.lib pxproc.dll (or lib...so)	Binary libraries (pxcore.lib is only for Windows static linking)
pypixet.pyd (or .so) pypxproc.pyd (or .so)	Python core and processing libraries See Python API
pxcapi.h common.h	Header for the binary compile with pxcore.dll/so See Binary core API
pixet.ini	Pixet core configuration file See: Files and directories of the Pixet and SDK - pixet.ini file
main.cpp SampleProject.vcxproj SampleProject.sln	Sample Visual studio project (Windows package only)
*.rbf *.bit	Firmware files
install_driver_rules.sh 60-opalkelly.rules 60-pixet.rules	Linux drivers installer and it's helper files
okFrontPanel.dll libokFrontPanel.so	Helper library of the zem.dll/so hwlib
ftd2xx.dll	Helper library of the minipix.dll (Windows only)
other files .dll (or .so - no lib...so)	Hwlib files (can be in separate directory) See: Files and directories of the Pixet and SDK - hwlibs
lic.info	License file for the Pixet core - not importatnt in this version, but may be in future
pdf files	Binary and python APIs manuals

Pixet core on Windows need more Microsoft Visual Studio .NET standard dlls (vccorlib140.dll etc).

Alternatives to run the API using programs:

1. Copy all need files to the Project directory.
2. While running the program, change the operating directory to the Pixet main directory.
3. Copy the binary executable or python script to the Pixet main directory and run it from here. Useful for occasional single test, but can do problems in more extensive cases.

Special files

Configuration XML files

The config file contains all detector settings and you can start and continue with the settings as it was while last program exit. The factory config is config saved afther low-level detector setup, finding of bad pixels, calibrations and other factory tests.

Notes:

- The detector cannot work properly if proper config not loaded.
- The files must have proper names. “WidePIX-B04-W0535-10.xml” for example. If not, automatic load at start will not work. To optain proper config name, you can do the program exit and see saved filename in the configs directory.

See:

- The factory and the configs subdirectories

pixet.ini file

This is the main configuration file of the Pixet core. It has several sections beginning with a title in square brackets. Sections contain configuration lines formated as Name=value or Name= for default value. They can also contain comments, which start with a semicolon. This way you can also deactivate some configuration lines.
Default version of the file conaining used options and all remaining options disabled + with =default. User can edit it and enable.

The default path where Pixet core looks for the pixet.ini file is the same as the path to the pxcore library. So the file should be next to it.
Attention:

- All paths listed in pixet.ini are relative to it
- All other paths are relative to the current directory.

So if you run c:\program files\pixet\pixet.exe from c:\users\myname:

- pxcore will try to load c:\program files\pixet\pixet.ini
- paths listed in pixet.ini (Hwlib, LogsDir, ...) can be relative to c:\program files\pixet\
- paths used in program (eq. for saving data) can be relative to c:\users\myname.

Old progams note: In some obsolette versions of API was path of pixet.ini relative to the program.

[Settings]

General settings of used directories, core and the Pixet program parameters:

- UseAppDataDir UseAppDataDir=true - Change default location of the configs and logs subdirs and ini files to the user data directory. It also allows different login users to have different settings of same devices in same programs.

  Note: This does not affects the factory directory.
  See: User data directory

- PixetIniInAppDataDir PixetIniInAppDataDir=true - Enable reading the pixet.ini file from the user data directory. Very usesful if the program is located in the Program files or at other location with no write rights. It also allows different users to have different pixet.ini. Note: Enabling this option means that the Pixet core first loads this file (from the program launch point) and, after detecting this option, loads it again from the user data directory. Other settings in the default pixet.ini are therefore ignored.

  See: User data directory

- PixetIni PixetIni=C:\myPixetAppData\myPixetIni1.ini - Change name and location of the pixet.ini file. Similar to the case of PixetIniInAppDataDir, when using PixetIni=, the initialization file will be loaded again and the contents of the original file will not affect the further operation of the software.
- AppDataDir AppDataDir=C:\myPixetAppData\group1 - Change location of the user data directory to specified path. Useful if user have more programs using a Advacam devices and want divide it to some groups with different settings.
- ConfigsDir ConfigsDir=C:\myPixetAppData\configsGroup1 - Change location od the configs dir to other location. Useful if user have more programs using a Advacam devices and want divide it to some groups with different settings of devices.
- FactoryDir FactoryDir=C:\myPixetAppData\factory - Change location od the factory dir to other location. Useful if user have many independent places of a programs, creating new programs and testing new devices. User can simply store all factory files in one location. Or it is possible to have such a directory on the company server, where users do not have the right to write.
- LogsDir LogsDir=C:\temp\pxCoreDebug - Change location of the logs directory. Useful if user have many independent places of a programs, typically if creating new programs. User can simply collect all logs to one directory so that he does not have to open another one every time.
- Splash Splash=true - Use a splash screen when the Pixet program starting. It does not affect programs using the API.
- FileDevice FileDevice=true - Enable virtual "file device" independent if physical devices connected.

  See: File device

- FileDeviceWhenNoDevs = FileDeviceWhenNoDevs=false - Disable virtual "file device" if no physical devices connected.

  See: File device

- SaveSettings SaveSettings=false - Disable automatic save device settings on exit pixet core. It affects Pixet as well as programs that use the API.
- MaxFrameMemory MaxFrameMemory=1024 - Change the frame memory limit for multiframe acquisitions. Reserved for future use, currently not used.
- MainUi MainUi=devcontrol - Change main user interface plugin of the Pixet program. User can programm your own

plugins and one can be used instead of the Pixet main window.
- LogLeaveOldLogs LogLeaveOldLogs=false - Disable archiving old log files sets.
- LogRotateCount LogRotateCount=15 - Change number of archived log directories.
- HighDPI HighDPI=true - Enable AA_EnableHighDpiScaling feature in QT GUI environment. Disable can work only in very old versions of Pixet. Currently is deprecated and allways on.

[Hwlibs]

List of hardware library files/paths used in startup to search and connect a devices. See the hwlibs subdirectory description for details.
Examples: Left is default Pixet configuration with hwlib files in the hwlibs subdirectory, right is simple arrangement with files in the program directory. Last line is disabled in both versions.

Hwlibs section example (dirs/flat structure)

```
[Hwlibs]                    [Hwlibs]
Hwlib=hwlibs\minipix.dll    Hwlib=minipix.dll
Hwlib=hwlibs\widepix.dll    Hwlib=widepix.dll
Hwlib=hwlibs\zem.dll        Hwlib=zem.dll
;Hwlib=hwlibs\zest.dll      ;Hwlib=zest.dll
```

Hwlibs section (old format, before 2025/09)

```
[Hwlibs]                [Hwlibs]
hwlibs\minipix.dll      minipix.dll
hwlibs\widepix.dll      widepix.dll
hwlibs\zem.dll          zem.dll
;hwlibs\zest.dll        ;zest.dll
```

User can disable some hwlibs using the ; symbol.

Warnings:

- The Hwlib= must be exactly Hwlib=, it case sensitive
- Up to release 1.8.3 the [Hwlibs] section contains lines without the = symbol. This is not compliant with the INI standard. The file format was changed late releases is not compatible with old. From the next version all data lines will starts with the name=.

List of HWLIB files: Windows / Linux

- Minipix: minipix.dll / minipix.so
- Widepix with Eth: zest.dll / zest.so
- Widepix with USB2: widepix.dll / widepix.so
- Advapix or Widepix with USB3: zem.dll (and aux. file okFrontPanel.dll - allways in the program directory) / zem.so + okFrontPanel.so
- Advapix new: abrd-hwlib.dll / abrd-hwlib.so
- And customer-specific files for motor driving, x-ray sources, etc.

[Plugins]

List of Pixet plugins files/paths. All files is by default in the plugins subdirectory.

Note
Some plugins are not only for GUI Pixet

Accessing specific files like as HDF5, TIFF
These plugins are also needed when using an API.

Warning:

- The Plugin= must be exactly Plugin=, it case sensitive

[PixelmanPlugins]

List of Pixet plugins files/paths with backward compatibility for old Pixelman program.
Warning:
This is very obsolette. Support for Pixelman related stuff (this ini section, file formats, etc) will be removed soon without replacement.

Device configuration ini files

Some devices can has configuration file. Theese files are located in the program main directory or in the user data directory if the UseAppDataDir=true option used. Files have names identical to the names of the corresponding HWlibs, ending with .ini. For example, the Ethernet Widepix uses HWlib zest.dll (or zest.so on Linux) and the configuration is stored in zest.ini.

There is usually no need to edit these files, you can find details about them in the device's manual.

Only for network devices it is sometimes useful to define IP addresses on which Pixet core should search for devices. Either because the general search does not work on the given network, or so that the program does not "steal" a device in another room. For example, in zest.ini, each device can has its own section and an IP address defined in it:

```
[Device0]
IP=10.10.1.30

[Device1]
IP=10.10.1.31
```

Device firmware files

Some devices need firmware files to upload while initialization process. These files are allways located in the program directory. Names are typically composed from HWlib name and readout chip name (zemtpx3.rbf for example).
List of this kind of files:
zestwpx.bit, zemwpxf.rbf, zemtpx3.rbf, zemtpx3quad.rbf, zemtpx.rbf, cyptpx3pix.rbf
Note: The standard Pixet distribution that comes with your device only contains the files for that device, so you usually won't see all of these files. And Minipix, for example, doesn't need any of it.

Insidious complications with files/dirs

Let's have the following program and with it pypixet.pyd and other necessary files:

```
import os
os.chdir("test-output")
import pypixet

print("pixet core init...")
pypixet.start()
pixet=pypixet.pixet
devices = pixet.devices()
dev = devices[0]

print("dev.doSimpleAcquisition (3 frames @ 1 sec) - start")
rc = dev.doSimpleAcquisition(3, 1, pixet.PX_FTYPE_AUTODETECT, "example.png")
print("dev.doSimpleAcquisition - end:", rc, "(0 is OK)")

pixet.exitPixet()
pypixet.exit()
```

This program normally works with e.g. Minipix, but does not work with e.q. Advapix. Crashes at pypixet.start() or has not any detected devices.

The problem is that hwlibs load their files eg firmware from the current directory. Minipix not need any other files, Advapix need a firmware .rbf file. Moving os.chdir after pypixet.start() solves the problem.

Related

- Pixet SDK overview
- The PIXet program
- File types